

GlazeGuard

Porcelain & Ceramic Sealer

2-Part Formula Mixing Instructions


STEP

1

POUR

Into Empty 5 Quart Container

STIR PART A
separately for **1 minute** until smooth, uniform color and consistency




Stir 1 minute

MIX RATIO

Gloss, Satin or Matte

Mix Ratio 3:A:1B by volume



Stir 2 minutes

STEP

2

MIX

Add Part B **slowly** and stir Part A & B **together** for 2 minutes

STEP

4

APPLY EVENLY

Use 3/8 inch Nap Non Shed Roller

NOTE: Product must be used within 60 minutes of mixing



6+
HOURS

FINAL STEP

5

APPLY EVENLY

LET DRY



5
min

STEP

3

WAIT

Let the mixed product **rest together** for 5 minutes



24
HOURS

Allow at least 8 Hr for light foot traffic or 24 for heavy foot traffic



Scanned to see

[Video](#)

More info @

covertecproducts.com

Still Need Help?
(888) 387-2059



IMPORTANT NOTES: Mix only enough material that can be used (applied) in 60 minutes

For best results, change out roller after 60 minutes of use



CoverTec
innovative chemistry for surface solutions

GlazeGuard



Application Instructions

Exterior /Wet Areas

BEGIN

The Brief

The surface must be properly prepared before applying GlazeGuard in outside areas and wet areas like restrooms and shower rooms. For long term results use 2 step cleaning process for surface preparation

use 2 step cleaning process for surface preparation

STEP 01

must be thoroughly cleaned with a high pH cleaner

Prepping of the Surface

Surface must be thoroughly cleaned with a high pH tile and grout cleaner like Crystal Clean CT-50. Apply cleaner and scrub with a nylon grit brush. Allow 15 minutes for the substrate cleaner to breakdown grease deposits and soiling. Flood the floor with water and extract with a wet vac

STEP 02

Etch Surface

Apply PreTreat to microscopically etch the surface at a rate of 400 sq.ft per gal using a pump sprayer or mop. Caution use a spray devise that will not create heavy misting or over spray. The surface should be kept wet with Pretreat for (15-20 minutes)

Test product in an inconspicuous area before applying
(cover metal surfaces)

apply PreTreat to microscopically etch the surface

For Vertical Applications

For Vertical applications like showerwalls a second Pretreat application is necessary. Rapply the second treatment after the first has dried out and allow to sit for 15 to 20 minutes and then rinsed away with clean, cold water. Scrubbing with a stiff wire brush or maroon scour pad may be necessary to remove heavy deposits of efflorescence or cement scale. Rinse thoroughly to remove residue and to ensure that it is pH neutral. If necessary neutralize the tile with neutral cleaner and squeegee off all excess of water. If no drains are available, use a wet-vac, then mop with fresh water. Allow the wall to dry before applying the tile.



CoverTec
innovative chemistry for surface solutions

GlazeGuard



Application Instructions

Exterior /Wet Areas

STEP

03

Use Microfiber Mop

Vacuum up all the dust. Use a microfiber floor cloth to pick up any final dust and dirt.

make sure surface
clear of any debris



STEP

04

Mix Part A with Part B

Use all mixed material
within 60 minutes

Mix Product Slowly

Pour Part A into a separated Mixing container and stir for 1 minute. Add the part B while mixing slowly for 2 minutes. Wait 5 minutes then product is ready to use.

NOTE: If required slowly mix in *CoverGrip anti-slip additive (4.0 oz per gal) or it can be broadcast into GlazeGuard once applied to the floor while it is still wet.



STEP

05

Roll On Coating

Must use a non-shed 3/8 inch nap microfiber roller and 4 or 6" mini rollers for the edges. Remove fur from roller before use by rolling up and down on tacky side of blue tape.

Do not starve the roller of product 12 to 16 sq ft per dip. When rolling out the material do not push down too hard. Use the weight of roller to roll out any lines. Overlap and maintain wet edge (white).

For best results use
roller tray to dip from

To avoid missed
spots make sure the
room is well lit

LET DRY



Dry time is 6 hours

Note: Varies based on
temperature, humidity and
environmental conditions



*CoverGrip clear white additive
provides durable anti-slip floor
in coatings and sealers.